



STATIC LINE DROGUE PACKING INSTRUCTIONS

Inspect every component during each pack job

- Step 1 Configure the system to static line drogue
- A) Remove other deployment systems
 - B) Attach light blue colored drogue & bridal to d-bag & top of canopy, tighten link ¼ turn past hand tight
 - C) Replace broken retainer bands and tube stows on the deployment bag (d-bag)
 - D) Release front riser trim tabs completely
- Step 2 Place canopy in proper layout on left side with good line tension and alignment
- Step 3 Complete 6 line check
Check rapid links and barrels
- Step 4 Untwist steering lines and set deployment brakes
- A) Insert white dacron loop thru control line cat eye
 - B) Flip guide ring over dacron loop and insert toggle tip thru the loop
 - C) Pull excess control line above its guide ring
 - D) Seat toggles on velcro
- RIGGER CHECK 1**
- E) Stow excess toggle line in velcro wrap
- Step 5 Split nose 4 ½ cells to each side and roll inward
- Step 6 Fold canopy with line groups centered in fabric and on top of each other
- A) Fold A lines half way to B lines then fold remainder on top of B lines
 - B) C lines on A,B lines
 - C) D lines on C,A,B lines
 - D) Steering lines on D,C,A,B lines
 - E) Clear stabilizers
 - F) Flake tail and split at center cell label
 - G) Ensure all lines are tight and clear of fabric
- RIGGER CHECK 2**
- H) Grasp the top center of the slider and carefully pull up the lines to the stops
 - I) Carefully quarter slider up into canopy between line groups
- RIGGER CHECK 3**
- J) Fold stabilizers and slider into two 45 degree angles
 - K) Pull center of tail down and wrap around folded stabilizers
 - L) Cocoon center cell tail fabric around canopy removing excess air

- M) Make small S fold with slider grommets sitting on top
- N) S fold remaining canopy on top of slider grommets (against knees)
- O) Expose ring at top of canopy where bridal attaches by folding fabric into top fold

Step 7 Pull d-bag over canopy while maintaining folds and preventing air from seeping in

- A) Make first three locking stows of suspension lines using black tube stows (center first)
- B) Make next two locking stows thru loops using tandem retainer bands (single wrap)

RIGGER CHECK 4

- C) Stow remaining suspension lines leaving approximately 18" above risers

Step 8 Bring the d-bag over the container

- A) Stow the risers with the toggles toward the reserve container
- B) Place a pack buddy or spectra pull-up cord thru the closing loop
- C) Cock the drogue inner bridal kill line so that green mark is visible

RIGGER CHECK 5

- D) Place d-bag in main container, orient disk with arrow pointing up into position and expose straight closing pin
- E) Route closing loop **COUNTER** clockwise thru main flap d-rings (match diagram on flap)
- F) Insert straight closing pin thru closing loop twist free (match diagram)
- G) Insert locking pin into closing pin and seat completely
- H) Ensure green mark on inner bridal kill line shows in window thru outer drogue bridal

RIGGER CHECK 6

- I) Narrow drogue and S-fold lengthwise into thirds
- J) Insert drogue (handle first) into blue static line drogue bag
- K) Close drogue bag & make locking stow with 2" bite of bridal using tandem retainer band
- L) S-fold remaining bridal across bottom of drogue bag without going over ends of bag
- M) Close flap over bridal folds and mate velcro
- N) Mate drogue bag to container velcro with blue static line coming out riggers left side
- O) Conceal remaining exposed bridal under main container side flap

RIGGER CHECK 7

- P) Tuck upper cover flap in place, close main closing pin protective flap & bottom tuck tabs
- Q) Stow **BLUE** static line from right to left on drogue d-bag with tandem band double wrapped
- R) Stow remaining static line from the upper right of main container to upper left, top to bottom using tandem bands double wrapped

Step 9 Log pack job in rig card and log sheet

RIGGER CHECK 8