

## Installation Instructions for HiPerLink Soft Connector Links



1) Check the continuity of your line group. Begin installation by inserting the link through all the lines and then through the riser.



2) Pass the link through the lines and through the riser again, so that the link forms a doubled loop.



3) Insert the small loop at the top of the link through the loop just above the stopper knot. It may be necessary to use a fid or ballpoint pen to open the loop slightly to allow insertion.



4) Using a fid, ballpoint pen, or similar object, carefully open the top loop a little wider to enable it to pass over the stopper knot. Make sure that you don't damage any of the fibers as you perform this step.



5) Now pass the widened loop over the stopper knot, then "milk" the finger-trapped portion of the link to return the top loop to its original smaller size.



6) Rotate the link so that the knotted portion is hidden inside the riser. Finally, pull the riser and suspension lines away from each other to tighten the connector link. It is important that the locking section of the link remain inside the riser, so for the first several pack jobs check for this. After a few jumps the link will take a "set" and have no tendency to rotate.



[www.HiPerUSA.com](http://www.HiPerUSA.com)