

## Closing instructions for TS 14 pulley closing loop

### Tools:

At least 84" spectra (550lbs, 725lbs or 1000lbs) pull up cord  
Pull bar or t-bodkin

### Instructions:

Feed pull up cord on short loop



Place main bag on container, put the disk on top of d-bag and feed the pull up cord backward. Feed the first one under, 2<sup>nd</sup> over 3<sup>rd</sup> over the pass the pull up cord through blue closing loop.



From here reverse your steps.



Feed the pull up cord through the last flap and start closing the container.



Once you pass the closing loop through the grommet place your closing pin.

